

INSTALLATION PROCEDURE

1. CLEAN THE WEEP HOLE.
FOR SAFETY PLEASE WEAR HAND GLOVES



2. USING PUSHER TOOL, SLIDE THE “WEEP HOLE COVER” IN PUSHER TOOL PINS, FOR EASY IDENTIFICATIONS, THOSE ARE 4 CIRCULAR HOLE SURROUNDED BY SMALL HEXAGONS.



3. WITH THE “PUSHER TOOL” SLIDE THE “WEEP HOLE COVER” INTO WEEP HOLE CAVITY.

**Must equally
spaced
with brick cavity
or Weep Hole**



NOTE: FOR QUICK INSTALLATION, MAKE SURE IT IS EQUALLY ALIGN THE WEEP HOLE CAVITY, IF WEEP HOLE CAVITY SMALLER THAN 7MM THEN MANUALLY BEND THE WEEP HOLE COVER ON PUSHER TOOL BEFORE INSTALLING INTO WEEP HOLE CAVITY.



THANKS FOR PURCHASING OUR PRODUCT.

OTHER PRECAUTIONS:

1. PLEASE LOOK AROUND WINDOWS FRAME, IF THERE IS ANY GAP PLEASE USE GAP FILLER TO FILL IT.
2. ALL DOORS WHICH HAVE A ACCESS OF YOUR HOUSE MAKE SURE INSTALL WEATHER STRIP (DO NOT USE BRUSH TYPE WEATHER STRIP).
3. CHECK BEHIND HOT WATER UNIT, AIR-CON UNIT INSTALL OUTSIDE OF THE HOUSE, MOSTLY THERE IS A WEEP HOLE CAVITY BEHIND IT, IF YOU CAN'T INSTALL "WEEP HOLE COVER" THEN MAKE SURE TO BLOCK THE ACCESS WITH SOME SUITABLE STUFF.
4. SOMETIME THERE IS A CAVITY NEAR OUTDOOR PLUMBING WORK AROUND HOT WATER UNIT, AIR-CON UNIT, OUTDOOR TAPS. IF IT HAPPEN, PROPER ACTION MUST BE TAKEN TO SECURE YOUR HOME
5. CUT THE BRANCHES OF TREE WHICH ARE HANGING NEAR/ON THE ROOF TO AVOID DIRECT ROOF CONTACT OF RODENTS..
6. ONCE YOU INSTALL "WEEP HOLE COVER" AND FIX TOP MENTION ISSUES, THERE IS NO OTHER EASY ACCESS FOR RODENTS.

PLEASE NOTE: AFTER TAKING ALL ABOVE MENTION STEPS, THERE IS NOT EASY ACCESS OF ENTERING AND EXITING OF RODENTS SO IF YOU HAVE ALREADY RODENTS INSIDE THE HOME SO PLEASE USE TRAP TO CATCH THEM.

IF YOU HAVE ANY OTHER QUESTION, ADVICE AND INQUIRY PLEASE FEEL FREE TO CONTACT US OR
EMAIL US TO "info@bpgroup.com.au"
PLEASE LIKE OUR FACEBOOK PAGE "RODENT FREE HOMES" AND COMMENT IT.